



# Assembly Instruction

## Holmfirth Flowerbed

(HTG060190/HTB060190/HTG080190/HTB080190)

List of parts:

- 2 long side frames
- 2 short side frames
- 2 cross connections of 3x10x85cm
- 32 screws of 6x70mm

1/ Put the raised flowerbed on a solid and even ground.

2/ Start by screwing a short side frame to a long side frame. Then screw the second short side frame and finally the second long side frame.

Step 3

3/ Finally fix the two cross connections with the vertical bars of the long side frames.

