


# Assembly Instructions




**No Butts Bin Co.**  
*Better Ash & Trash Solutions*  
Est. 1991

Email : [Sales@nobutts.com](mailto:Sales@nobutts.com)  
Web : [www.nobutts.com](http://www.nobutts.com)  
Tel : 1-888-662-8887

Product code: SR1552

Doc. No.: SR1552-01-040116-USA

## EXPLODED VIEW



### Tools required:



Drill/Screwdriver



Mallet



Hack saw

### Tools included:























Wrench





Torx bit

## PARTS LIST


ITEM NO.	PART NO.	DESCRIPTION	DIMENSION	IMAGE	QTY.
1	S1	Frame	$78\frac{3}{4} \times 40\frac{3}{4}$		6
2	CB1	Bracket	$4\frac{1}{3} \times 4\frac{1}{3} \times 1\frac{1}{2}$		6
3	JF1	Bracket	$8\frac{5}{8} \times 1\frac{1}{2}$		6
4	ST1	Roof Tie	$40\frac{3}{8}$		2
5	RB1	Bracket	$4\frac{3}{8} \times 1\frac{1}{2}$		12
6	R1	Rafter	$44\frac{3}{4}$		4
7	SS	Sealing Strip	Cut to suit		6
8	PCE1	Roof Panel	$45\frac{1}{4} \times 41\frac{3}{8}$		2
9	PCC1	Roof Panel	$45\frac{1}{4} \times 40\frac{5}{8}$		1
10	RC1	Roof Strip	$44\frac{1}{2}$		4
11	2MD	Roof Edge Trim	trim to $61\frac{7}{8}$		4
12	FT1	Bracket	$4\frac{1}{4} \times 3\frac{7}{8}$		8

Fittings	Bolt set M10			T25	T50		BTANCM12100	$1\frac{1}{2} \times 1\frac{1}{2}$ End Caps
	$3/8\text{th} \times 2\ 3/8\text{'}$	Nut	Washer	1" Tech screw	2" Tech screw	Black Caps	$1/2 \times 4\text{'}$ Concrete Bolt	
Pack B	33	33	66	136	40	66	11	
Required	28	28	56	72	32	56	8	8
Spare	5	5	10	64	8	10	3	
Image								


**Step 1** Assemble main structure (**S1 Frames**) using **CB1** and **JF1** Brackets.




**Step 2** Attach **ST1** Roof Tie and Final **S1** to the structure using **CB1** and **JF1** Brackets.




**Step 3** Bolt the **FT1** Foot Brackets to the bottom of the frames and secure in desired position using ground anchor bolts.



**Step 4** Screw **RB1** Brackets to the top of the frame and bolt **R1** Rafters to framework.




**Step 5** Attach **Sealing strips (SS)** to rafters then place **PCE1** and **PCC2** Panels on top of the strips leaving a small gap between each.






**Step 6** Secure panels in place using an **RC1** Strip and screws, then attach the **2MD** edge trim to the edge of the panels.

**GENERAL NOTE:**  
THE 2" TECH SCREWS ARE  
FOR FIXING ROOF STRIPS  
(RC) ONLY



# Ground anchor positions and overall size

Scale 1:15



NOTES:

# **THANK YOU FOR PURCHASING THIS PRODUCT**

## **MAINTENANCE:**

To ensure your products give you many years of use we recommend that you:

- Clean panels regularly with soapy water
- Ensure all fitting are tight (for example after a big storm)
- Touch up any exposed metal should it get scratched

## **CONTACT DETAILS:**

Email : Sales@nobutts.com

Web : www.nobutts.com

Tel : 1-888-662-8887

No Butts Bin Company, Inc. 16 Birch Lane, Madison, CT 06443

<b>All Parts and Fixing checked by:</b>	
<b>Print Name:</b>	<b>Signature</b>