


Adult Picnic Table



Assembly Guide

NBB
Recycled
Furniture

NBB
Outdoors

NBB
Floor
Matting

Parts and Fittings

Table Top

Two People required
for safe assembly




x1

Bench Seat



x2

A-Frame Leg Components



x3

Fittings



x24



x24



x48

Tools supplied




17mm Spanner

x1


6mm Allen Key

x1

Step 1 Place table top on a soft, flat surface.




Step 2 Assemble the A frames by attaching the legs to the cross beams with the nuts and bolts supplied, using 2 washers per bolt.




Do not over-tighten bolts during assembly as small adjustments will help parts fit.

Step 3 With the table top in place attach the legs in the orientation shown below, with the nuts and bolts supplied, using 2 washers per bolt. Use both the spanner and the allen key to secure the bolts.




Do not over-tighten bolts during assembly as small adjustments will help parts fit.

Step 4 Flip table using two people.





Step 5 Place seats on A-Frames and fasten with bolts supplied.





NOTE: Only 1 hole used on seat brace

Activity Top Attachment Assembly Guide

Step 1 - Align the activity top centrally on the tabletop. Drill and screw the plastic angle through the activity top and into the side of table.



Step 2 - Attach the corner caps by drilling and screwing through into the sides of the tabletop.



Notes:

Notes:

THANK YOU FOR PURCHASING THIS PRODUCT

CONTACT DETAILS:

Email : sales@recycledfurniture.co.uk

Web : www.recycledfurniture.co.uk

Tel : 0800 1777 052

NBB Recycled Furniture, Unit 5, 145 Sterte Road, Poole, Dorset BH15 2AF

All Parts and Fixings checked by:	
Print Name:	Signature