

Assembly Instructions

2.4m Wood Picnic Table


WPT004-01-270422




PicnicTable

Superior Picnic Tables Made In The UK

Contents:



X1



X3





X2



Fixings	QTY
M10x80mm Bolt	12
M10 Nut	12
M10 Washer	24

Tools Required: 17mm Spanner

Step 1: Lay the tabletop on a soft surface and bolt the a-frames to the tabletop using x4 M10x80 bolts.



Step 2: With at least two people, flip the table the right way up and bolt the seats into the a-frames.



Maintenance:

15 years guarantee.

If damaged, repair and treatment is required.

Can be cleaned with soapy water.

Dependent on environment, more frequent treatment may be required.

Pressure treated tanalised timber (Class 4, BS EN 335-1 for direct contact with soil and fresh water).

Contact: Tel - 08081751903 **Email** - sales@picnictable.co.uk
Web - picnictable.co.uk

THANK YOU FOR YOUR BUSINESS