
Assembly Instructions

1.5m Wood Picnic Table

WPT002-01-270422







Step 1: Lay the tabletop on a soft surface and bolt the a-frames to the tabletop using x4 M10x80 bolts.

Step 2: With at least two people, flip the table the right way up and bolt the seats into the a-frames.

Step 3: Flip the table again and screw the diagonals into the a-frame crossbars and the middle table support.





Maintenance:

15 years guarantee.

If damaged, repair and treatment is required.

Can be cleaned with soapy water.

Dependent on environment, more frequent treatment may be required. Pressure treated tanalised timber (Class 4, BS EN 335-1 for direct contact with soil and fresh water).

Tel: 0800 1777 052 • Email: sales@nobutts.co.uk • Web: nobutts.co.uk

Thank You For Your Business