























## Parts List

	Dimensions	Quantity	Figure
Bench foot	-----	2	
Seat element	4x200x46,75cm	1	
Back element	4x200x22,25cm	1	
Screws	Ø 5 x 60 mm Ø 6 x 120 mm	6 8	
Bit	torx, size 25	1	
Silicone (brown)		1 tube	

## Parts List

	Dimensions	Quantity	Figure
Bench foot	-----	2	
Seat element	6x200x40,5cm	1	
Back element	6x200x26,25cm	1	
Screws	Ø 8 x 70 mm Ø 6 x 120 mm	4 8	
Cap + O-ring	Ø 18 mm	4	
Bit	torx size 25 torx size 40	2	
Silicone (brown)		1 tube	


## Parts List

	Dimensions	Quantity	Figure
Bench foot	-----	2	
Seat element	4x200x40,25cm	1	
Back element	4x200x19cm	1	
Screws	Ø 8 x 70 mm Ø 6 x 120 mm	2 4	
Cap + O-ring	Ø 18 mm	2	
Bit	torx size 25 torx size 40	2	
Silicone (brown)		1 tube	

## Required tools


- Tape measure or folding rule
- Power drill, electric screwdriver or screwdriver with bit-adapter
- Twiest drill Ø = 6 mm

## Step 1




Position the bench feet upright and parallel to each other about 100 cm apart.

## Step 1




Position the bench feet upright and parallel to each other about 100 cm apart.

## Step 1




Position the bench feet upright and parallel to each other about 100 cm apart..

## Step 2




Place the seat element on the feet. Fit the connecting irons on the seat into the recesses of the bench feet and fix it with screws (5x60 mm).

## Step 2




Place the seat element on the feet. Fit the connecting irons on the seat into the recesses of the bench feet and fix it with screws (8x70 mm) after placing an O-ring.

## Step 2




Place the seat element on the feet. Fit the connecting irons on the seat into the recesses of the bench feet and fix it with screws (8x70 mm) after placing an O-ring. .

## Step 3




Place the backrest on the feet and fix it with the screws by using the predrilled holes. 2 screws per bench board (6x120 mm).

## Step 3



Place the backrest on the feet and fix it with the screws by using the predrilled holes. 2 screws per bench board (6x120 mm).

## Step 3



Place the backrest on the feet and fix it with the screws by using the predrilled holes. 2 screws per bench board (6x120 mm).

## Step 4




Set the bench in a concrete foundation and fix it while drying. Do not use while drying.  
Fill the screw head at the backrest with silicone.

## Step 4



Set the bench in a concrete foundation and fix it while drying. Do not use while drying.  
Fill the screw head at the backrest with silicone.

## Step 4



Set the bench in a concrete foundation and fix it while drying. Do not use while drying.  
Fill the screw head at the backrest with silicone.