


# Assembly Instructions

## Cycle Shelter 2m




















# Health & Safety Information



| Tools Required   |                     |   |             |  |
|--|---------------------|---|-------------|--|
|  | Drill / Screwdriver |  | Hacksaw     |  17mm Spanner |
|  | Mallet              |  | Hand Clamps |  |

# Parts List


| Item No | Part Code   | Description           | Dimensions (mm) | Dimensions (inches) | Image   | Qty |
|---------|-------------|-----------------------|-----------------|---------------------|---|-----|
|         |             | Instructions          |                 |                     |    | 1   |
| 1       | <b>CTB</b>  | Central Tie Bar       | 1950            | 76.8                |    | 3   |
| 2       | <b>SP</b>   | Side Panel (Optional) | 1815 x 1965     | 71.5 x 77.4         |    | 2   |
| 3       | <b>RP1</b>  | Outside Roof Panel    | 3050 x 2010     | 120.1 x 79.1        |    | 1   |
| 4       | <b>KIF</b>  | Internal Foot         | 155             | 6.1                 |    | 4   |
| 5       | <b>KST</b>  | Straight Tie Assembly | 1535            | 60.4                |    | 2   |
| 6       | <b>KRF</b>  | Rear Frame Assembly   | 2115 x 985      | 83.3 x 38.8         |   | 2   |
| 7       | <b>KFF</b>  | Front Frame Assembly  | 1975 x 990      | 77.7 x 39           |  | 2   |
| 8       | <b>EC50</b> | Plastic End Cap       | 50 x 50         | 2 x 2               |  | 2   |

| Fittings |                     |                         |         |           |   |     |     |                           |
|----------|---------------------|-------------------------|---------|-----------|---|-----|-----|---------------------------|
| 9        | <b>MB1</b>          | M10 x 70 Bolt           | 10 x 70 | 0.4 x 2.8 |  | 4   |     |                           |
| 10       | <b>MB2</b>          | M10 x 20 Bolt           | 10 x 20 | 0.4 x 0.8 |  | 28  |     |                           |
| 11       | <b>N1</b>           | M10 Nut                 |         |           |  | 4   |     |                           |
| 12       | <b>W1</b>           | M10 Washer              |         |           |  | 36  |     |                           |
| 13       | <b>W2</b>           | M12 Washer              |         |           |  | 4   |     |                           |
| 14       | <b>T25</b>          | Tek Screw               | 25      | 1         |  | 110 | 158 | with optional side panels |
| 15       | <b>BC</b>           | Black Caps              |         |           |  | 40  |     |                           |
| 16       | <b>BTANC M10100</b> | M10 x 100 Concrete Bolt | 10x 100 | 0.4 x 3.9 |  | 4   |     |                           |

# Ground Anchor & Overall Size

Suggested size for concrete base: 200mm / 7.87in oversized (on all four sides)

■ mm  
■ inches



# Stage 1      Assemble Side Frames

## You will need

| Item No | Part No | Description           | Qty |
|---------|---------|-----------------------|-----|
| 5       | KST     | Straight Tie Assembly | 2   |
| 6       | KRF     | Rear Frame Assembly   | 2   |
| 7       | KFF     | Front Frame Assembly  | 2   |
| 10      | MB2     | M10 x 20 Bolt         | 16  |
| 12      | W1      | M10 Washer            | 16  |




17mm Spanner




Align all holes and loosely fit the bolts before fully tightening



The joined 3 frame sections make the **Complete Side Frame (CSF)**




**IMPORTANT**  
Ensure all holes are in correct position before assembling



# Stage 2      Attach Tie Bars to Left Frame

You will need

| Item No | Part No     | Description              | Qty |
|---------|-------------|--------------------------|-----|
|         | <b>LCSF</b> | Left Complete Side Frame | 1   |
| 1       | <b>CTB</b>  | Central Tie Bar          | 3   |
| 10      | <b>MB2</b>  | M10 x 20 Bolt            | 6   |
| 12      | <b>W1</b>   | M10 Washer               | 6   |



# Stage 3      Attach Right Frame

You will need


| Item No | Part No     | Description               | Qty |
|---------|-------------|---------------------------|-----|
|         | <b>RCSF</b> | Right Complete Side Frame | 1   |
| 10      | <b>MB2</b>  | M10 x 20 Bolt             | 6   |
| 12      | <b>W1</b>   | M10 Washer                | 6   |



17mm Spanner





Align all holes and loosely fit the screws before fully tightening





# Stage 4 Affix Roof Panel & End Caps

## You will need


| Item No | Part No | Description | Qty |
|---------|---------|-------------|-----|
| 3       | RP1     | Roof Panel  | 1   |
| 8       | EC50    | End Cap     | 2   |
| 14      | T25     | Tek Screw   | 110 |

|   |                     |
|---|---------------------|
|  | Drill / Screwdriver |
|  | Clamps              |

 Hold panel to frame using clamps before screwing into place



 Offer panel to the shelter as shown and secure in place using **T25** Tek Screws. Recommended 1 screw every 200mm / 8"



**PLEASE NOTE**   
Always clean off swarf when fixing the roof panels to avoid rust stains




# Stage 5 Affix Feet Brackets

## You will need


| Item No | Part No            | Description   | Qty |
|---------|--------------------|---------------|-----|
| 4       | <b>KIF</b>         | Internal Foot | 4   |
| 9       | <b>MB1</b>         | M10 x 70 Bolt | 4   |
| 11      | <b>N1</b>          | M10 Nut       | 4   |
| 12      | <b>W1</b>          | M10 Washer    | 4   |
| 13      | <b>W2</b>          | M12 Washer    | 4   |
| 15      | <b>BC</b>          | Black Caps    | 40  |
| 16      | <b>BTANCM10100</b> | Concrete Bolt | 4   |


|   |                            |
|---|----------------------------|
|  | <b>Drill / Screwdriver</b> |
|  | <b>17mm Spanner</b>        |

 Use at least 2 people to move shelter to desired location



 Move shelter to desired position and place **KIF** Foot into each leg. Adjust the shelter until level then drill through the foot and secure with **MB1** Bolts.



 Finally, fit **BC** Black Caps on all exposed nuts and bolts

## Notes



# **Thank you for purchasing this product**

## **Maintenance**

**To ensure your products give you  
many years of use we recommend that you:**

- **Clean panels regularly with soapy water**
- **Ensure all fittings are tight (for example after a big storm)**
- **Touch up any exposed metal should it get scratched**