


# Assembly Instructions



## EXPLODED VIEW



### Tools required:



Drill/Screwdriver



Spanners



Mallet






















Torx bit




Hack saw

# PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	DIMENSION	IMAGE	QTY.
1	B1	Beam	2100		1
2	WB1	Bracket	45 x 45 x 30		3
3	L1	Bracket	95 x 45 x3		8
4	R6	Rafter	1035		3
5	L3	Bracket	73 x 38 x 3		2
6	L2	Bracket	52 x 38 x 30		2
7	S3	Frame	2000 x 500		1
8	B2	Beam	2100		1
9	SS	Sealing strip	Trim to 1110		2x 10m ROLL
10	PCE1	Roof Panel	1150 x 1050		2
11	S3	Frame	2000 x 500		1
12	2MD	Roof Edge Trim	2000		3
13	RC3	Roof Strip	cut to suit		3
14	FT1	Foot Bracket	109 x 100 x 3		4
15	EC	End Caps	40 x 40		8


Fittings								T50	
	M8 x 20	M10 x 60	M10 Nut	M8 Washer	M10 Washer	M8 Black Cap	M10 Black Cap	50mm Tech screw	M10x100mm Concrete Bolt
QTY.	3	35	35	3	70	3	70	35	4
Image									

**Step 1** First attach the **WB1** brackets to the wall at the correct distance as shown below. Then bolt the **L1** brackets to the **B1** Beam before fixing the beam to the wall.








**Step 2** Fix the two **R6** end rafters to the **L1** Brackets, then attach the **S3** frame using **L2** brackets at the rear and **L3** brackets at the front of the frames.




**Step 3** Use two **L1** brackets to secure the front beam (**B2**). Also attach the Central rafter (**R6**) using four more **L1** brackets.




**Step 4** Make sure the shelter is square before attaching the **FT1** floor fixing brackets.



**Step 5** Apply two lengths of **SS** Sealing strips on each rafter. Attach the **2MD** roof strips the the roof sheets first, then use the 50mm Tec screws to fix the roof sheets into place.




**Step 6** Apply six more **SS** sealing strips to the top of the roof sheet and line them up with the ones underneath. Then align the **RC3** roof strips and use 50mm Tec screws to secure them.





# PLAN VIEW

## OVERALL DIMENSIONS AND GROUND FIXING POSITIONS



NOTES:

# THANK YOU FOR PURCHASING THIS PRODUCT

## **MAINTENANCE:**

To ensure your products give you many years of use we recommend that you:

- Clean panels regularly with soapy water
- Ensure all fittings are tight (for example after a big storm)
- Touch up any exposed metal should it get scratched

## **CONTACT DETAILS:**

Email : Sales@shelters4less.co.uk

Web : [www.shelters4less.co.uk](http://www.shelters4less.co.uk)

Tel : 0800 160 1002

Shelters4Less, Unit 3, 2 Lansdowne Crescent, Bournemouth, BH1 1SA

<b>All Parts and Fixings checked by:</b>	
Print Name:	Signature: