


Assembly Instructions




No Butts Bin Co.
Better Ash & Trash Solutions
Est. 1991

Email : Sales@nobutts.com
Web : www.nobutts.com
Tel : 1-888-662-8887

Shelter type: SR1602

SR1602-03-191016-USA

EXPLODED VIEW



Tools required:



Drill/Screwdriver



Mallet



Hack saw

Tools included:




















Wrench




Torx bit

PARTS LIST


ITEM NO.	PART NO.	DESCRIPTION	SIZE	IMAGE	QTY.
1	S1	FRAME	$78\frac{3}{4} \times 40\frac{3}{4}$		3
2	JF1	PLATE / BRACKET	$8\frac{5}{8} \times 1\frac{1}{2} \times \frac{1}{8}$		5
3	CB1	BRACKET	$4\frac{3}{8} \times 4\frac{3}{8} \times 1\frac{1}{2}$		4
4	S3 (M3)	FRAME	$78\frac{3}{4} \times 20\frac{3}{8}$		1
5	S3 (M4)	FRAME	$78\frac{3}{4} \times 20\frac{3}{8}$		1
6	L3	BRACKET	$2\frac{7}{8} \times 1\frac{1}{2} \times \frac{1}{8}$		2
7	RB2	BRACKET	$4\frac{3}{8} \times 1\frac{6}{8} \times \frac{1}{8}$		8
8	R3	CURVED RAFTER	$40\frac{3}{4}$		4
9	L1	BRACKET	$3\frac{3}{4} \times 1\frac{3}{4} \times \frac{1}{8}$		6
10	B3	BEAM	$61\frac{7}{8}$		2
11	PCE1	ROOF PANEL	$45\frac{1}{4} \times 41\frac{3}{8}$		2
12	P3	POST	$78\frac{1}{2}$		1
13	PCC2	ROOF PANEL	$45\frac{1}{4} \times 40\frac{1}{2} \times \frac{5}{8}$		1
14	2MD	ROOF EDGE TRIM	$6\frac{7}{8}$		4
15	RC1	ROOF STRIP	$44\frac{1}{2}$		4
16	SS	SEALING STRIP	Cut to suit		1
17	FT1	BRACKET	$4\frac{1}{4} \times 4 \times \frac{1}{8}$		7

Fittings	Bolt set M10 3/8th x 2 3/8"	Nut	Washer	Black Cap	T25	T50	AB1210	$1\frac{1}{2} \times 1\frac{1}{2}$ End Caps
					1" Tech screw	2" Tech screw	1/2 x 4" Concrete Bolt	
Pack A	30	30	60	60	72	30	8	
Required	30	30	60	60	52	20	7	8
Spare	0	0	0	0	20	10	1	
Image								


Step 1 Assemble **S1** frames to make up the main structure using **CB1** brackets in the corners and **JF1** brackets on the straight joints.




Step 2 Attach **R3** rafters using **RB2** brackets on the back of the shelter and **L3** brackets in the middle.



Step 3 Attach front beams (B3) and centre post (P3)




Step 4 Attach the **FT1** foot brackets, Move the Shelter into its final position and make sure its square. Then use concrete anchor bolts to secure it to the the ground.




Step 5 Attach **PCE1** roof panels and **RC1** cover strips using 2" Screws. Push on the **2MD** edge trim. Then fit the Black plastic caps on exposed nuts and bolts. Fit the square end caps to any open ends of box sections.

GENERAL NOTE:
THE 2" TECH SCREWS ARE
FOR FIXING ROOF STRIPS
(RC) ONLY



PLAN VIEW

OVERALL DIMENSIONS AND GROUND FIXING POSITIONS



Suggested size for
concrete base:
8" oversized on all
four sides.

NOTES:

NOTES:

THANK YOU FOR PURCHASING THIS PRODUCT

MAINTENANCE:

To ensure your products give you many years of use we recommend that you:

- Clean panels regularly with soapy water
- Ensure all fittings are tight (for example after a big storm)
- Touch up any exposed metal should it get scratched

CONTACT DETAILS:

Email : Sales@nobutts.com

Web : www.nobutts.com

Tel : 1-888-662-8887

No Butts Bin Company, Inc. 16 Birch Lane, Madison, CT 06443

All Parts and Fixing checked by:	
Print Name:	Signature: