

# Assembly Instructions




**No Butts Bin Co.**  
*Better Ash & Trash Solutions*  
Est. 1991

Email : [Sales@nobutts.com](mailto:Sales@nobutts.com)  
Web : [www.nobutts.com](http://www.nobutts.com)  
Tel : 1-888-662-8887

**Product code: SR7896-F**

Doc. No.: SR7896F-01-191021-USA

# EXPLODED VIEW AND TOOLS



**Tools required:**



Drill/Screwdriver



Mallet


















Wrench



Torx bit

# PARTS LIST AND FITTINGS



ITEM NO.	PART NO.	DESCRIPTION	Size (inch)	IMAGE	QTY.
1	S1C	S1 - Full Frame - SRC	78.74 x 40.74		8
2	CB1	Corner Bracket - CB1	4.3 x 4.3 x 1.57		8
3	JF1	Joint Flat - JF1	4.33 x 1.57		9
4	ST3	Roof Tie - ST3	81.1		1
5	EC40	40x40 PLASTIC END CAP	1.57 x 1.57		2
6	FT1	FT1 BRACKET	1.57 x 1.57 x 3.94		2
7	FT3	FT3 Bracket	1.57 x 3.15 x 4.17		7
8	DR	Rafter Bracket	4.3 x 1.6 x 2		16
9	DR1R	Rafter	45		5
10	DR1I	Infill Panel	44.6 x 7.9		2
11	DR1PO	Roof Panel Outer	47.7 x 41.5		2
12	DR1T	Roof Trim	47.7 x 3.1		5
13	DRATO	DR Ally-Angle Trim Outer	2 x 2 x 41.5		4
14	DR1PI	DR1 Roof Panel Inner	47.6 x 40.75		2
15	DRATI	DR Ally-Angle Trim Inner	2 x 2 x 40.75		4

Fittings	Bolt set M10				T25	T38	AB1210
	M10 x 60mm	Nut	Washer	Black Cap	25 mm Tech screw	38 mm Tech screw	M10/12 x 100 mm Concrete Bolt
<b>Pack A+B Required</b>	40 19	40 19	80 38	80 38	136 100	66 30	13 9
<b>Image</b>							


**Step 1** Assemble **S1** frames to make up the main structure using **CB1** brackets for the corners and **JF1** brackets for straight joints. Also use **CB1** and **JF1** brackets to secure the **ST3** tie bar.

NOTE: Insert **EC40** into **ST3** before installation.



Check overall dimensions to ensure correct alignment





DETAIL A  
SCALE 1 : 7




**Step 2** Attach the **DR1R** rafters using the **DR** brackets and 1 inch tech screws. The Infill panels (**DR1I**) are also attached using 1 inch tech screws but must be placed into position at the same time as the end rafters.



**Step 3** Arrange the roof panels by lining up the end panels (**DR1PO**) flush with the outer rafters and equally space the middle pieces (**DR1PI**) between the outers. Seal the gaps between the panels and the outer edges with the **DR1T** strips. Then cap the bottom of the rafters using the **DRATO** and **DRATI** angles.



**Step 4** Move the shelter into its final position and attach the floor brackets. **FT1** brackets are used where there is only a single leg and **FT3** brackets used where there are two legs next to each other.







# THANK YOU FOR PURCHASING THIS PRODUCT

## MAINTENANCE:

To ensure your products give you many years of use we recommend that you:

- Clean panels regularly with soapy water
- Ensure all fitting are tight (for example after a big storm)
- Touch up any exposed metal should it get scratched

## CONTACT DETAILS:

No Butts Bin Company, Inc.  
16 Birch Lane, Madison, CT 06443

Email: [Sales@nobutts.com](mailto:Sales@nobutts.com)

Web: [www.nobutts.com](http://www.nobutts.com)

Tel: 1-888-662-8887

<b>All Parts and Fixing checked by:</b>	
Print Name:	Signature